

**Product** Air temperature sensor  
**Serial number** 7Y3332  
**Date of calibration** 31 July 2020

# Calibration certificate

**Specification** Air temperature sensor accuracy ±0.2 °C

**Measured values and uncertainties of calibration**

Reference sensors mean temp.(°C)	0.03	10.03	20.03	30.02	40.01
Sensor mean temperature (°C)	0.03	10.03	20.02	30.02	40.01
Mean temperature error (°C)	0.00	0.00	-0.01	0.00	0.00

	<b>Max error</b>	<b>Uncertainty (k=2)</b>
Air temperature sensor error	-0.01 °C	±0.04 °C

Reference standards	Ref. no.	UKAS	Certificate no.	Calibration date
Reference resistor	EC/003	0152	U305902	19 <sup>th</sup> February 2020
Reference resistor	MTE/920	0152	U305901	19 <sup>th</sup> February 2020
Reference semi-standard PRT	RUK28125	0175	20-04-31	6 <sup>th</sup> April 2020
Reference semi-standard PRT	MTE/878	0175	20-04-32	6 <sup>th</sup> April 2020

Authorised signature	Signatory	Position	Issue date
	Chris Hunt	General Manager	31 <sup>st</sup> July 2020

*This certificate may not be reproduced other than in full, except with the prior written approval of:*

**Renishaw plc**  
 Laser & Calibration Products Division  
 Bath Road, Woodchester  
 Stroud  
 Gloucestershire  
 GL5 5EY  
 United Kingdom  
 Tel +44 (0) 1453 524524

**Certificate number**  
**7Y3332-200731-01**

L-9908-0901/02

# Calibration notes

1. **Lasers (XM, XL, ML, HS and RLU)** are calibrated by comparison to a reference HeNe laser using an optical beat frequency technique. Reference lasers are routinely calibrated against an iodine-stabilised HeNe laser supplied by the National Physical Laboratory (NPL), or by a national standards laboratory. All frequency measurements are taken over a 1 hour period.
2. **Air pressure and relative humidity (RH) sensors are installed in a compensator (XC and RCU).**  
The air pressure sensors are calibrated over 650 mbar to 1150 mbar range in a temperature controlled oven by direct comparison with a reference pressure meter. The RH sensors (where fitted) are certified by the manufacturer to be within specification. They are calibrated by comparison of the readings with those from a reference RH meter at a single applied humidity.
3. **Air and material temperature sensors (XC and RCU)** are calibrated by direct comparison with transfer platinum resistance thermometers (PRTs) in a temperature controlled water bath over 0 °C to 40 °C (50 °C for material sensor). The transfer PRTs are routinely calibrated against reference PRTs.
4. **Rotary axis calibrators (XR20)** are calibrated using a HeNe laser angular interferometer.
5. **Ballbar transducers (QC20-W and QC10)** are calibrated using a HeNe laser interferometer. The scale factor (QC10 only) is calculated and must be entered into the Renishaw application software prior to use.
6. **Ballbar calibrators** are calibrated by direct comparison with a reference ballbar calibrator (calibrated by a national standards laboratory) using a reference ballbar as a transfer standard. The measured values for the ballbar calibrator must be entered into the Renishaw application software prior to use.
7. **Traceability.** All the reference standards (listed overleaf) used in these calibrations are traceable either directly to major international metrology institutes who have signed the CIPM Mutual Recognition Agreement (e.g. NPL: UK; LNE: France; NIST: USA; PTB: Germany; NMIJ: Japan) or to a national accreditation body (e.g. UKAS: UK; A2LA: USA).
8. **Environment.** The equipment used for calibration is in a facility held between 15 °C and 25 °C.
9. **Uncertainty calculations.** The uncertainty calculations have been carried out according to the European Co-operation for Accreditation document EA-4/02.
10. **Quality accreditation.** All calibrations above are covered by Renishaw's ISO 9001 quality assurance system. The system is audited and certified by an accredited agency.
11. **Re-calibration.** Customers may wish to confirm that systems are performing within published specifications over time. If so, it is recommended that they should be periodically re-calibrated. Please note that compensators and temperature sensors are re-calibrated only at a single applied temperature, air pressure and humidity. Please refer to the appropriate system manual for further details.